



# VideoClip HD8 AutoPlay Setup Guide

## AutoPlay Functionality

Setting up the VideoClip's AutoPlay functionality couldn't be easier; this guide includes instructions on setting it up. We've split the Guide into 3 simple sections; please read the steps below. If you require any further support, we advise you follow the link below and fill in the form.

[www.interpretationshop.co.uk/support](http://www.interpretationshop.co.uk/support)

### 1. Trigger Cable

The VideoClip has been setup before dispatch. For AutoPlay functionality the 'Trigger Cable' will be already connected to the VideoClip on Button 8. Insert the 3.5mm Jack into the Trigger Cable input (as shown in the diagram).

### 2. Splitter Cable



You then must connect the 3.5mm Jack end of the Splitter Cable into your VideoClip audio output (as labelled in the diagram).

### 3. Handset Connection

Once these cables are connected to the shown connections, insert the 3.5mm Jack from your Handset into the Splitter Cable (as shown in the diagram).

#### Note:

Your AutoPlay Content must be programmed into folder 01 on your SD Card. It's important to be aware that button inputs 01 & 08 are reserved when in AutoPlay mode, button inputs 02-07 can be programmed as normal.



Web: [www.interpretationshop.co.uk/product/lightbox-3/](http://www.interpretationshop.co.uk/product/lightbox-3/)

Tel: +44 (0)1639 874 100

Email: [sales@blackboxav.co.uk](mailto:sales@blackboxav.co.uk)