



VideoClip HD8 Double Cup Headphones AutoPlay Setup Guide

AutoPlay Functionality

Setting up the VideoClip's AutoPlay functionality with Double Cup Headphones couldn't be easier; this guide includes instructions on setting it up. Please read the steps below. If you require any further support, we advise you follow the link below and fill in the form.

www.interpretationshop.co.uk/support

1. Headphone Connection

Insert the Headphone's 3.5mm Jack into the Audio port on the VideoClip

2. Hanger Cable



You then must connect the black, yellow and blue cables from the Hanger into the Terminal-to-3.5mm Jack (as labelled in the diagram).

3. Hanger Connection

Once these cables are connected to the shown connections, insert the 3.5mm Jack from your Handset into the I/O port on your VideoClip (as shown in the diagram).

Note:

Your AutoPlay Content must be programmed into folder 01 on your SD Card. It's important to be aware that button inputs 01 & 08 are reserved when in AutoPlay mode, button inputs 02-07 can be programmed as normal. This is typically set up for you prior to dispatch.



Web: www.interpretationshop.co.uk/product/lightbox-3/

Tel: +44 (0)1639 874 100

Email: sales@blackboxav.co.uk