



Message In A Speaker PLUS Looping



- 1 Audio Looping**
The indoor audio player will play your track on a constant loop/repeat.
- 2 Status LED**
The LED indicates the players state.
- 3 Wall Mount**
Easily mount the player onto a suitable surface via rear mounts, or use the supplied ball and socket bracket.
- 4 Great Audio Quality**
Audio is output via a class D 15W amplifier providing great sound quality.
- 5 Power On/Off**
Turn the device on/off via the 12V power supply.
- 6 Micro SD Card Slot**
Store your content with a Micro SD Card (128MB supplied).
- 7 Volume Button**
Adjust the players volume with the built-in control.
- ✓ Colour**
Choose between black or white.

Technical Information

Play Modes - Using your Micro SD Card

In order for the device to read your track, you must name it to 01.mp3

Looping Mode

Looping Mode will repeatedly play 1 track, without being triggered by the motion sensor.

If you have multiple audio files, stitch them together into one track beforehand.

Please follow the steps below:

1. Place your track onto the Micro SD Card named 01.mp3
2. A config file needs to be placed within the Micro SD Card. Please download this file on the 'downloads' section of the product page.
3. Upon receiving the file, all you need to do is drag onto your card.

How to revert your Message In A Speaker PLUS - Looping Mode to Sequential / Random Mode

1. Open the rear of the player by undoing the 4 screws.
2. Disconnect the wire link.
3. Connect the PIR wire.
4. Refer to the Message In A Speaker PLUS - Standard spec sheet for uploading content in Sequential / Random Mode;
<https://www.interpretationshop.co.uk/product/message-in-a-speaker-plus/#tab-downloads>

Unit Weight	1.331Kg
Unit Dimensions	145mm x 122mm x 189mm
Power Supply	DC12V
Message Storage Medium	Micro SD Card - Max. 32GB (Supplied 128MB)
Message Encoding Format	.MP3, .WAV
Audio Bitrate	128Kbps
Operating Voltage	9-24V DC
Operating Current	≤2000mA
Standby Current	≤30mA
Consumption Current at Playback	≤500mA (12V DC)
PIR Range	≤6m in 120° angle
Included	1 x MIAS+, 1 x U-Shaped Mount, 1 x Ball & Socket Mount, 1 x Power Adapter, 1 x Micro SD Card, Fixing Screws

Mounting Options



U-Shaped Mount



Ball & Socket Mount

U-Shaped Mount

Screw the U-Shape into a wall surface and slot in the MIAS+. Lock into place using the supplied screws.

Ball & Socket Mount

Screw the socket mount into a wall surface. Then screw the ball onto the device using the top screw hole. Slot the Ball & Socket together and lock into place by tightening the socket mount.

Related Products



Large PIR Sensor



Message in a Speaker



SoundClip-8



Small PIR Sensor